



INSTALLATION GUIDE

PAROC® HVAC LAMELLA MAT BLACKCOAT



INSTALLATION INSTRUCTIONS FOR CIRCULAR AND RECTANGULAR VENTILATION WITH PAROC® HVAC LAMELLA MAT BLACKCOAT

STEP 1

Cut the lamella mat with a knife (e. g. PAROC® Pro Knife) to the appropriate length equal to the external circumference of the insulated duct:

- for **circular ducts**:
 $\pi \times [D + 2 \times \text{insulation thickness}]$
- for **rectangular ducts**:
 $[2 \times \text{length side A}] + [2 \times \text{length side B}]$
+ 8 x thickness insulation)
plus add about 2-3 cm.

STEP 2

Place the lamella mat on the **circular duct** with the BlackCoat aluminium foil on the outside so that its ends hang loosely.

STEP 3

Apply welding pins (PAROC® Head Pins BlackCoat or PAROC® Head Pins Insulated) on the surface of the **rectangular duct** (8-10 pieces per 1 m²), then place the lamella mat on the pins and secure it against slipping with self-locking clips. Cut the ends of the pins above the cap.

STEP 4

For **rectangular ducts**, the insulation should touch the frames connecting the individual duct elements. The joints, insulated on both sides in this way, should be fixed along the perimeter with self-adhesive PAROC® BlackCoat Tape.

STEP 5

Press both ends of the lamella mat to the surface of the duct and connect them with PAROC® BlackCoat Tape.

STEP 6

In case of tension or compression on the BlackCoat Aluminium foil and for insulation of ducts bigger than 200 mm diameter, it is absolutely necessary to add metal bands, taking care that they are not too tight and will not cut or damage the facing.



PAROC® HEAD PIN BLACKCOAT

PAROC® HEAD PIN INSULATED

PAROC® BLACKCOAT TAPE

PAROC® PRO KNIVES

PAROC® HVAC LAMELLA MAT BLACKCOAT

STEP 7

Add next lamella to the duct, following the instructions given in with points 1-4.

STEP 8

Connect the joints using PAROC® BlackCoat Tape.

STEP 9

The ends of insulation should be covered by a cuff, adjusted to the thickness of the mat.

STEP 10

Before installing the lamella, cut out holes for all kinds of elements on the duct, such as fittings, valves, tees, fasteners, etc.



Notes:

- The thickness of the insulation should be designed appropriately according to the operating parameters of the installation and the conditions in the room, otherwise the glued joints may be damaged. The surface temperature of the BlackCoat aluminium foil during operation at the maximum operating temperature should not exceed 80 °C.
- PAROC® Hvac Lamella Mat BlackCoat can be used for all types of indoor installations, provided that the maximum operating temperature does not exceed 250 °C.
- When high insulation thickness is required, PAROC® Hvac Lamella Mat BlackCoat can be installed in two layers, placing the joints of mat fragments away each other to prevent thermal bridges.
- Do not walk on the previously made insulation during the installation process, as this may cause damage to it.
- When insulating outdoor installations, additional protection is needed.
- Dry and clean the BlackCoat surfaces well before fixing them on the mat ends in order to obtain a good quality of the joints. The self-adhesive tape should be firmly pressed with the help of a spatula.
- BlackCoat facing may show some irregularities due to production process.
- Head Pins must be insulated.

SELECT THE CORRECT INSULATION THICKNESS

Outer diameter	Thermal conductivity coefficient of the insulating material [W/(mK)]															
	0.035		0.036		0.037		0.038		0.039		0.040		0.041		0.042	
	I	O	I	O	I	O	I	O	I	O	I	O	I	O	I	O
63	40	80	42	84	43	88	45	93	47	97	49	102	51	107	53	112
80	40	80	42	84	43	88	45	92	47	96	48	100	50	105	52	109
100	40	80	42	84	43	87	45	91	46	95	48	99	50	103	51	107
125	40	80	41	83	43	87	44	90	46	94	48	98	49	102	51	106
150	40	80	41	83	43	87	44	90	46	93	47	97	49	101	50	104
160	40	80	41	83	43	86	44	90	46	93	47	97	49	100	50	104
200	40	80	41	83	43	86	44	89	46	93	47	96	49	99	50	102
250	40	80	41	83	43	86	44	89	45	92	47	95	48	98	50	101
300	40	80	41	83	43	86	44	89	45	92	47	94	48	97	49	101
315	40	80	41	83	43	86	44	89	45	91	47	94	48	97	49	100
400	40	80	41	83	43	85	44	88	45	91	46	94	48	97	49	99
500	40	80	41	83	42	85	44	88	45	91	46	93	47	96	49	99
600	40	80	41	83	42	85	44	88	45	90	46	93	47	96	49	98
630	40	80	41	83	42	85	44	88	45	90	46	93	47	96	49	98
800	40	80	41	83	42	85	44	88	45	90	46	93	47	95	49	98

*I - air heating pipes (placed inside the thermal insulation of the building),
O - air heating pipes (placed outside the thermal insulation of the building)*



PAROC SALES OFFICES AND CONTACTS

Headquarter / Finland

Paroc Group Oy / Paroc Oy Ab
P.O. Box 240
FI-00181 Helsinki, Finland
Energiakuja 3
Phone: +358 46 876 8000
Email: [Contact us in Finland](#)



Belgium / The Netherlands / France

Email: [Contact us in Belgium French](#)
Email: [Contact us in Belgium Dutch](#)
Email: [Contact us in Netherlands](#)
Email: [Contact us in France](#)



Denmark

Paroc Danmark Filial af PAROC AB
Helsingør Erhvervspark A/S
H P Christensensvej 1
DK-3000 Helsingør
Tel. +45 49 12 10 00
Email: [Contact us in Denmark](#)



Estonia

AS Paroc
Pärnu mnt 158
EE-11317 Tallinn, Estonia
Tel. +372 651 8100
Email: [Contact us in Estonia](#)



Germany / Switzerland / Austria

Paroc GmbH
Heidenkampsweg 51
D-20097 Hamburg, Germany
Tel. +49 40 33 49 60000
Email: [Contact us in DACH area](#)



Latvia

SIA Paroc
Vienības gatve 109
Rīga, LV-1058, Latvia
Tel. +371 7 339053
Email: [Contact us in Latvia](#)



Lithuania

UAB Paroc
Savanoriu 124
03153 Vilnius, Lithuania
Tel. +370 5 2740 000
Email: [Contact us in Lithuania](#)



Norway

Paroc AB Norge
Rosenholmveien 25
NO-1414 Trollåsen, Norway
Tel. +47 22 64 59 00 / 01
Email: [Contact us in Norway](#)



Poland

Paroc Polska sp. z o.o.
ul. Gnieźnieńska 4
62-240 Trzemeszno, Poland
Tel. +48 61 468 21 90
Email: [Contact us in Poland](#)



Sweden

Paroc AB
SE-541 86 Skövde, Sweden
Visiting address: Bruksgatan 2
Tel. +46 500 469 000
Email: [Contact us in Sweden](#)



The United Kingdom / Ireland

Owens Corning Insulation (UK) Ltd
31-35 Kirkby Street
London EC1N 8TE
The United Kingdom
Email: [Contact us in UK & Ireland](#)



The information relating to the products and systems contained in this communication ("Information") is accurate and reliable to the best of our knowledge as of its date issued and is subject to change without prior notice. No guarantee of accuracy is given or implied.

Since Paroc has no control over installation workmanship, accessory materials or conditions of application, no express or implied warranty of any kind, including those of merchantability or fitness for a particular purpose or course of performance or usage of trade, is made as to the performance of an installation containing Paroc products.

While the Information in this communication may relate to the technical application of certain Paroc products, it is in no event to be considered as technical advice on the basis of which Paroc may incur any liability.

User is solely responsible for determining whether a Paroc product is fit for a particular purpose and suitable for user's method of use or application.

Users of the provided Information assume full responsibility for all concept/design decisions made relating to the suitability of use.

Users must rely on their own judgment or that of a concept/design professional when determining how to best apply the data provided.

Users agree that Paroc is under no obligation to provide additional details, testing or test data on its behalf.

Liability of Paroc, if any, is strictly limited to replacement of product. In no event shall Paroc be liable for any other damages arising because of product failure, whether incidental, special, consequential or punitive, regardless of the theory of liability upon which any such damages are claimed.

